SERVICE MANUAL

AEP Model

Chassis No. SCC-B66E-A





BE-1 CHASSIS

Note: The service manual for RM-658 has been issued separately.

MODELS OF THE SAME SERIES								
KV-M16D								
KV-M19D/M19TD								
KV-M14D								

SPECIFICATIONS CCIR B, G and H

Television system

Color system

Channel coverage

PAL SECAM VHF E2 - S20

UHF E21 - E69

Picture tube

Trinitron tube 90° degree deflection

Approx. 40.1cm (16 inches)

(Approx. 37.3 cm picture measured

diagonally)

Input

21 - pin connector : CENELEC

standard AV connector

Output

Earphone jack: minijack 21 - pin

connector: CENELEC standard

Power consumption

Dimensions

Approx. $389 \times 374 \times 413$ mm

(W/H/D)

Weight

Approx. 12.8kg

Supplied accessories

RM - 658 Remote Commander (1)

IEC designation R6 batteries (2)

Sound output


3.5w (music power)

Design and specifications are subject to change without notice.





21-pin Euro Connector Configuration



PIN	SIGNAL	SPECIFICATION
1	Audio output	0.5Vrms/1kilohm or less
2	Audio input	0.5Vrms/10kilohms or more
3	Audio output	0.5Vrms/1kilohm or less
4	Earth (audio)	
5	Earth (B-input)	
6	Audio input	0.5Vrms/10kilohms or more
7	B-input	0.7∨p-p/75ohms
8	Function switching	9.5V to 12V
9	Earth (G-input)	
10		
11	G-input	0.7√p-p∕75ohms
12		
13	Earth (R-input)	
14	Earth (blanking)	
15	R-input	0.7Vp-p/75ohms
16	Fast blanking	1V to 3V/75ohms
17	Earth (video)	
18	Earth (fast blanking)	
19	Video output	1Vp-p/75ohms
20	Video input	1∨p-p/75ohms
21	Screening plug	


TABLE OF CONTENTS

Sec	<u>tion</u>	\underline{Title} \underline{P}	Page
1.	GEN 1-1.	NERAL Function of Controls	. 3
	1-2. 1-3.	On The Remote Commander To Preset Channels	
2.	DIS	ASSEMBLY	
	2-1.	Rear Cover Removal	. 5
	2-2.	B Board Removal	. 5
	2-3.	Picture Tube Removal	. 6
	2-4.	Service Position	. 7
3.	SET	-UP ADJUSTMENTS	
	3-1.	Beam Landing	. 8
	3-2.	Convergence	. 9
	3-3.	Focus	. 10
	3-4.	White Balance	. 11

<u>Secti</u>	<u>Title</u>	<u>Page</u>
4.	CIRCUIT ADJUSTMENTS	
	4-1. B Board Adjustments	
	4-2. D Board Adjustments	12
5.	DIAGRAM	
	5-1. Circuit Boards Location	
	5-2. Schematic Diagram (1)	14
	5-3. Printed Wiring Boards (1)	17
	5-4. Schematic Diagram (2)	20
	5-5. Printed Wiring Boards (2)	23
	5-6. Semiconductors	
6.	EXPLODED VIEWS	
	6-1. Chassis	25
	6-2. Bezel	26
7.	ELECTRICAL PARTS LIST	

SECTION 1 GENERAL

1-1. FUNCTION OF CONTROLS



On the set

On-screen display

Indicates program numbers and input mode; .

Press the button to make the display appear on the screen, and again to make it disappear. See also "On the Remote Commander" below.

Bar display

Indicates the level of the user controls when they are adjusted; \triangle volume, \bigcirc contrast or \bigcirc color.

① power switch


To cut off the mains electricity supply, press this switch. Ensure correct operation by pressing the switch fully.

Remote control detector

Point the Remote Commander towards this detector.

standby indicator

Lights up brightly when the set is in standby mode.



Inside the panel

arphone jack (minijack mono)

nreset button

analogue select buttons

Press repeatedly until the on-screen display of the required adjustment appears (\triangle volume, \bigcirc contrast or \bigcirc color). Adjust by using the \triangle + or - buttons.

G input button

Press this button to view the input picture coming in through the 21-pin connector or the \bigcirc connectors on the front panel. " \bigcirc " appears on the screen. Press \bigcirc again or PROGR + \bigcirc – to return to the TV mode.

Extra equipment can be connected to the TV using both the 21-pin connector and the input connectors, but only one piece of equipment besides the TV should be turned on at one time.

prightness control

Turn clockwise for more brightness or anticlockwise for less.

✓ Volume adjustment buttons +/-

Use these buttons to adjust the volume to the desidered level.

PROGR +/- buttons

Use to scan the available channels. To turn on the TV from standby mode without using the remote commander, press any of these buttons.

♂ Video ∕ Audio input connectors (phono)

Connect to a VTR, micro-computer, etc.


o V (Yellow) video input

o A (Black) audio input (mono)

Note

The TV button does not function on this set.

1-2. ON THE REMOTE COMMANDER



To operate the Commander, point it toward the remote control detector.

M mute button

Use to mute the sound. Press ∠ + or 🕅 to restore the

0,9, 1-, 2-buttons

To select:

program 15, press 1 - and 5, program 25, press 2 - and 5.

→·← normal button

Press to return color and contrast to factory-set levels.

(standby button

Press to select standby mode. Use this facility to turn off the set for short periods of time.

To return to TV mode, press TV or the program number on the Remote Commander; there will be a slight delay before the picture is restored. If the main power is turned off when in standby mode, the indicator will take 2 to 6 seconds to go off.

Press to view the input picture from the 😇 connector or TV mode.

1-3. TO PRESET CHANNELS

Use the buttons inside the Panel, To open the panel, push and pull the centre.

Manual Programming

To Tune in a Channel in Any Desired Program Position

- Press \Rightarrow (preset) to select the presetting mode.
- Select the desired program position by using the PROGR + or - button.
- Press ∠ + or repeatedly until the TV program of the desired channel appears.
- Repeat steps 2 and 3 for all desired channels.
- Press again to return to the TV mode.

On-screen display button

Indicate the program number and the input mode. Press this button to make the display appear on the screen, and press the button again to make it disappear.

TV button

Press to change to the TV mode from standby, G input modes.


PROGR+/- buttons

Use to scan the available channels.

- ∠ + / − volume buttons
- Color buttons
- contrast buttons


G input button

G connectors. "G" appears on the screen. Press G PROGR +/- or a program number key to return to the




SECTION 2 DISASSEMBLY

2-1. REAR COVER REMOVAL



2-2. B BOARD REMOVAL




1) Pull the clips in the direction of arrow 2). Remove the B bracet in the direction of

-5-

arrow **(b)**.

3 Install the B board in the direction of arrow @.


2-3, PICTURE TUBE REMOVAL




Removing Procedures




1 Turn up one side of the rubber cap in the direction indicated by the arrow 3.



- 2 Using a thumb, pull up the rubber cap firmly in the direction indicated by the arrow .
- 3 When one side of the rubber cap is separated from the anode button, the anode cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow©.



2-4. SERVICE POSITION



SECTION 3 SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed,
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

The control and switch below should be set as follows unless otherwise noted:

◆ CONTRAST control ······ 80% (or Normal by Commander)

☆BRIGHTNESS control 50%

Perform the adjustments in order as follows:

- 1. Beam Landing
- 2. Convergence
- 3. Focus
- 4. White Balance

Note: Test Equipment Required.

- 1. Color Bar/Pattern Generator
- 2. Degausser
- 3. DC Power Supply
- 4. Digital multimeter
- Oscilloscope


Preparation


- Set the side of the unit with the PICTURE TUBE so that it faces east or west in order to reduce the influence of external magnetic force.
- Turn the power switch for the unit ON and erase the magnetic force using a degausser.

3-1. BEAM LANDING

- 1. Input a raster signal with the pattern generator.

 CONTRAST | normal | normal |
- 2. Turn the raster signal of the pattern generator to red.
- Move the deflection yoke backward, and adjust with the purity control so that red is in the center and blue and green are at the sides, evenly.
 (Fig. 3 - 1 to 3 - 3)
- 4. Move the deflection yoke forward, and adjust so that the entire screen becomes red.(Fig. 3 1)
- 5. Switch over the raster signal to blue and green and confirm the condition,
- 6. When the position of the deflection yoke is determined, tighten it with a deflection yoke mounting screw.
- 7. When landing at the corners is not right, adjust by using the magnet. (Fig. 3 4)










Fig.3-4




3-2. CONVERGENCE

Preparation:


- Before starting, perform FOCUS, H. SIZE and V. SIZE
- Set BRIGHTNESS control to minimum.
- Feed in the dot pattern.
- (1) Horizontal and Vertical Static Convergence





- 1. Adjust H. STAT VR to coincide red, green and blue dots on the center of screen.(Horizontal movement)
- 2. Adjust V. STAT magnet to coincide red, green and blue dots on the center of screen.(Vertical movement)
- 3. If the red, green and blue dots do not coincide on the center of screen with H. STAT VR, perform horizontal convergence adjustment using H. STAT VR and V. STAT magnet as shown below. (In this case, H. STAT VR and V. STAT magnet effect each other.)
- Tilt the V. STAT magnet and adjust static convergence to open or close the V. STAT magnet.



4. When the V. STAT magnet is moved in the direction of arrow @ and b, red, green and blue dots move as shown below.








If the red and blue dots do not coincide with green dot, perform following steps.

Move BMC magnet (a) to correct insufficient H. static convergence.

Rotate BMC magnet (b) to correct insufficient V. static convergence.

In either case, repeat Beam Landing Adjustment.




(2) Dynamic Convergence Adjustment


Preparation:


- Before starting, perform Horizontal and Vertical Static Convergence Adjustment...
- 1. Slightly loosen deflection yoke screw.
- 2. Remove deflection yoke spacers.

- 3. Move the deflection yoke for best convergence as shown
- 4. Tighten the deflection yoke screw.
- 5. Install the deflection yoke spacers,



(3) Screen-corner Convergence





3-4. WHITE BALANCE

(Screen (G2) Setting)


- 1. Input dot signals from the pattern generator.
- Apply 140 V DC to the cathodes of R, G, and B from an external power source.
- 4. While watching the picture, adjust the G2 volume BRIGHTNESS controls are set to normal unless otherwise (RV703) immediately before the fly-back line disappears. specified,

(White Balance Adjustment)

- 1. Input all-white signals from the pattern generator.
- 2. Adjust the BRIGHTNESS and COLOR controls to the standard level.
- 2. Set the picture BRIGHTNESS control to the minimum 3. Adjust the white balance using RV701 (B DRIVE) and RV702 (G DRIVE).

In the following adjustments, the CONTRAST COLOR and

SECTION 4 CIRCUIT ADJUSTMENTS




4-1. B BOARD ADJUSTMENTS

REF OSC Adjustment (CT301)

- 1. Input a PAL COLOR BAR pattern.
- 2. Short circuit between pin $\mathfrak D$ of IC301 and ground.
- 3. Adjust CT301 to obtain color synchronization.
- 4. Remove the jumper wire from IC301.


1H DELAY LINE Adjustment (L303 DAT, RV301 DAR)

- 1. Input a PAL COLOR BAR pattern.
- 2. Connect the oscilloscope to pin ③ (B-Y) of IC301 and observe the waveform of the H block on the oscilloscope.
- 3. Adjust L303 to minimize the double waveform outline.



4. Input a PAL TEST COLOR BAR pattern.

5. Rotate the RV301 VR and adjust till the ANT PAL part of the waveform matches the 0 level.



6. L303 and RV301 affect each other, so repeat till the conditions of both are met.

Y TRAP 4.25 MHz ADJUSTMENT (L308)

- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect pin (§) of IC302 to the oscilloscope and adjust L308 so that the waveform level becomes minimum.




SECAM ID Adjustment (L306)

- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect a Digital Multimeter at pin 20 of IC301.
- 3. Adjust L306 so that the indicator goes up to the maximum.


BELL FILTER Adjustment (T301)

- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect an oscilloscope to the Q302 emitter.
- 3. Adjust T301 so that the waveform becomes flat.



SECAM DISCRI Adjustment (L304 R-Y L305 B-Y)

- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect an oscilloscope to pin ① of IC301.
- 3. Adjust L304 (R-Y) so that white and black parts of the waveform of pin ① becomes 0 level.
- 4. Connect an oscilloscope to pin 3 of IC301,
- 5. Adjust L305 (B-Y) so that white and black parts of the waveform of pin 3 becomes 0 level.




SUB BRT Adjustment (RV302)

- 1. Input a PAL COLOR BAR signal.
- Set CONTRAST and COLOR volume to a minimum, and set the BRIGHTNESS volume control to the mechanical center.
- Slowly rotate SUB BRT (RV302) until the red portion is faintly illuminated.

4-2, D BOARD ADJUSTMENTS


TU AGC (RF AGC)

- 1. Tune in air signals.
- Adjust AGC VR (RF AGC) so that snow-noise and cross-modulation just disappear from the picture.




H. FREQ (RV553)

- Input a PAL COLOR BAR signal, then connect an electrolytic capacitor (100 μ/16V) between Pin (5) and GND of IC551.
- 2. Adjust RV553 (H. FREQ) to stop scrolling of the picture in the horizontal direction.
- 3. After adjustment, remove the electrolytic capacitor.



SECTION 5 DIAGRAM

5-1. CIRCUIT BOARDS LOCATION



5-2. SCHEMATIC DIAGRAM (1)

Note:

- All capacitors are in μ F unless otherwise noted.pF: μμ F
 50WV or less are not indicated except for electrolytics.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5mm Rating electrical power: 1/4W

- All resistors are in ohms.
- : nonflammable resistor.
- - tusible resistor.
- panel designation.
- adjustment for repair.
- All variable and adjustable resistors have characteristic curve B,unless otherwise noted.
- All voltages are in V.
- lacktriangle Readings are taken with a 10M Ω digital multimeter.
- Readings are taken with a PAL colour-bar signal input. () SECAM
- Voltage variations may be noted due to normal production tolerances.
- B+line
- signal path.


Reference information


RESISTOR : RN METAL FILM
: RC SOLID
: FPRD NONFLAMMABLE CARBON
: FUSE NONFLAMMABLE FUSIBLE
: RS NONFLAMMABLE WIREWOUND
: RB NONFLAMMABLE CEMENT


COIL : LF-8L MICRO INDUCTOR


COIL : LF-8L MICRO INDUCTO CAPACITOR : TA TANTALUM

5 6 7 8 9 10 11 3 Y-CHROMA JUNGLE V.H ĐEF C012 I









(1)

2

(3)

4

5

(6)

Z

1Vp-p (H) VIF101 (VIDEO)

0.95Vp-p (H) IC401(13)

 \mathbb{W}

3.7Vp-p (4MHz) IC001(29)

4.8Vp-p (V) IC001(50)

IC001(51)

Bare President President Price


1.8Vp-p (H) IC551(5)

(POWER)




IC		D405	C-3
IC001 IC002 IC003 IC004 IC005	B-11 C-12 J-13 C-9 A-9	D406 D407 D408 D410 D411	D-2 D-2 D-2 B-2 E-2
IC401 IC402 IC501	E-7 C-2 B-2 G-1 I-1	D413 D414 D415 D416 D419	B-1 C-4 C-3 A-3 C-4
IC601 IC801 IC851	E-9 G-2 E-6	D420 D421 D501 D551	A-4 G-1 I-2
TRANS	ISTOR	D601	F-11
Q001 Q003 Q004 Q005 Q008	A-11 B-11 B-9 C-9 A-12	D602 D603 D604 D605 D606 D607	
Q009 Q012 Q015 Q071 Q151	B-12 C-12 B-8 C-5 E-2	D608 D609 D610 D611 D801	F-10 E-9 E-9 I-10 I-5
Q152 Q154 Q155 Q158 Q402 Q403	E-2 E-3 E-4 E-5 B-3 C-3	D802 D851 D852 D853 D855	I-4 J-6 J-6 G-7 G-6
Q404 Q405 Q406	C-3 E-2 B-5	D857 D858	G-5 G-6
Q501 Q551	H-2 A-2	VARIA RESIS	
Q601 Q801 Q802 Q803 Q804	E-9 J-3 J-5 H-3 I-3	RV401 RV501 RV552 RV553 RV801	C-13 G-2 H-1 J-2
		RV802	G-3
DIO			
D002 D003 D004 D005 D007	B-11 B-10 F-13 J-13 E-13		
D008 D009 D010 D011 D016	D-13 D-13 D-13 A-12 D-11	10 m	
D017 D019 D025 D151 D156	A-10 C-10 C-12 C-8 E-3		
D201 D402 D403 D404	C-8 D-1 D-1 D-1	v	


F BOARD



D BOARD ICO02 CXK1012P



D BOARD IC551 TDA2579A-N7



5-4. SCHEMATIC DIAGRAM (2)


15


3 8 9 10 11 12 13 14 FOCUS SCREEN B TO Đ BOARĐ CNĐ82 C326 R321 R348 33x (CHROMA DECODER) TO D BOARD (CND43) V901 A37JUW10X PICTURE TUBE CNB32 C TO Đ BOARĐ CNĐ83 D 0706 BF871 R-OUT E DEO | CNB33 CNB31 U6W-H B OUT ₽318 1SS133 B-BLK 9316 9317 155133 9-BLK R-BLK ≢ R736 2.2k F G **B BOARD WAVEFORM** C BOARD WAVEFORM H 3 4 (5) (3) 4 1 J my -9-[] -0-[Mahah 1.4Vp-p (H) IC301 (3) 0.95Vp-p (8.86MHz) IC301 (9) 0.6Vp-p (H) IC301 (5) 1.5Vp-p (H) IC301 (2) 1Vp-p (H) IC301 4 64Vp-p (H) 72Vp-p (H) 56Vp-p (H) 22Vp-p (H) Q709 (E) Q708 (E) Q707 (E) H1-H2 (6) (8) 9 JWWJI 2.2Vp-p (H) IC302 1 2.2Vp-p (H) IC302 (3) 2.2Vp-p (H) IC302 (5) 0.4Vp-p (H) IC302 (15)



B (CHOROMA DECODER)


5-5. PRINTED WIRING BOARDS (2)
B BOARD






C (R. G. B OUT)

C BOARD



B BOARD IC302 TDA3505-V9



5-6. SEMICONDUCTORS

BX - 1398



TDA2579-N7



BC637-16



DTA114ES DTA124ES DTC114ES DTC124ES DTC143TS

ERC06 - 15S R₂M



L78M05CX L78M12CV



MC14053BCP

16 1514131211 10 9

VISTA PALL' ALTO

TC4053BP

MAB8461P-W136 TDA3505-V9 TDA4555-V8 μPD4364CX-15L



CXK1012P

TEA2014A

μPC4558C

BF199 BF871

BF421

2SC2688



KBU4J

JA101-Q JC501-Q






MC921



M50436-616SP M50436-618SP



HZT33-02 µPC574J

VISTA PALL' ALTO



LATO CON LETTERE

188133 188148 HZS3.6NB2 HZS3.9NB1 HZS5.6NB1 HZS6.8NB1 **HZS9.1NB1 HZS9.1NB3** HZS12NB1



SAA5243E



µPC1488H

CATODO




BF819



CQS51L-4

CQY24BL-4

STR54041






2SA1091

2SC2060

BU506DF



BYT33G BYT51D BYT52G ERA81-004 GP08D RGP01-17 RGP10G RGP15J



TDA1013A



2SD1761-F



- CATODO ANODO


SECTION 6 EXPLODED VIEWS

NOTE:

- · Items with no part number and no des-
- Tems with no part number and no description are not stocked because they are seldom required for routine service.
 The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


The components identified by shading and mark Aare critical for safety.
Replace only with part number specified.

6-1. CHASSIS



REF.NO. PART NO.	DESCRIPTION	REMARK REF.NO. PART NO. DESCRI	PTION REMARK
1 4-389-302-01 2 *4-388-955-01 3 *4-374-987-01 4 *A-1345-840-A 5 *A-1135-562-A 6 A. 1-463-881-11 7 A. 1-439-432-11 8 *1-628-600-11	BRACKET (B), LIGHT GUIDE GUIDE, LIGHT D BOARD, COMPLETE B BOARD, COMPLETE TUNER, ET (UV-617)		PUSH (AC POWER) POWER AC CORD WER (WITH CONNECTOR) REAR (BLACK)

6-2. BEZEL



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.N	NO. PART NO.	DESCRIPTION	REMARK
60	X-4389-323-1 X-4389-323-3 4-374-714-01 4-382-732-11 4-391-417-01 4-391-418-01 4-391-421-01 1-503-344-21 4-391-423-01 8-738-852-05 3-703-961-01 1-451-304-21 1-452-277-00	BEZNET ASSY (BLACK) BEZNET ASSY (WHITE) CATCH, PUSH SPRING BUTTON, POWER ORNAMENT, BUTTON, POWER WINDOW, ORNAMENTAL SPEAKER (SCM CONE TYPE) HOLDER, SPEAKER PICTURE TUBE (A37JUW10X) SPACER, DY DEFLECTION YOKE (Y16SXA) MAGNET, BMC	52-58 52-58	63 64 65 66 67 68 69 70 71 72 73 74 75	*4-385-422-01 *A-1330-946-A & 1-426-317-21 4-369-318-00 *4-374-704-01 *4-374-717-01 X-4389-322-2 4-382-733-01 X-4309-608-0 1-452-032-00 1-452-094-00 4-391-450-01 3-701-007-00	HOLDER, LEAD C BOARD, COMPLETE COIL, DEGAUSSING SPRING, TENSION COVER (REAR LID), CV VOL COVER (MAIN), CV VOL DOOR ASSY SCREW (S), PT PERMALLOY ASSY, CONVERGENCE MAGNET, DISK; 10MM \$\phi\$ MAGNET, ROTATABLE DISK; 15MM (CUSHION, CRT BAND, BINDING	ð

SECTION 7 ELECTRICAL PARTS LIST

NOTE:

The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified. • Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

When indicating parts by reference number, please include the board name.

All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

CAPACITORS • MF : אר, PF : אען

RESISTORS

• All resistors are in ohms • F : nonflammable

GOILS • MMH : mH, UH : "Н

REF. NO	. PART NO.	DESCRIPTION	 -		REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
	*A-1135-562-A	B BOARD, COM				C348 C349 C350 C351		MYLAR MYLAR ELECT CERAMIC	0.022MF 0.022MF 33MF 68PF	10% 10% 20% 5%	250V 250V 50V 50V
	<cap< td=""><td>ACITOR></td><td></td><td></td><td></td><td> </td><td></td><td></td><td>220MF</td><td>20%</td><td>16V</td></cap<>	ACITOR>							220MF	20%	16V
C301 C302 C303 C304 C305	1-106-220-00 1-124-120-11 1-101-005-00 1-106-367-00 1-102-971-00	MYLAR ELECT CERAMIC MYLAR CERAMIC	0.1MF 220MF 0.022MF 0.01MF 82PF	10% 20% 10% 5%	100V 16V 50V 400V 50V	C352	1-124-120-11 <con *1-560-126-00<="" td=""><td>NECTOR></td><td></td><td></td><td>104</td></con>	NECTOR>			104
C306 C307 C308 C309	1-101-006-00 1-101-004-00 1-101-888-00 1-102-816-00	CERAMIC CERAMIC CERAMIC CERAMIC	0.047MF 0.01MF 68PF 120PF	5% 5%	50V 50V 50V 50V	CNB32	*1~565~393~11 *1~565~393~11	CONNECTOR, B	OARD TO BO	ARD	
C310	1-102-978-00	CERAMIC	220PF	5%	50V	CT 301	1-141-392-11	CAP. VAR. TR	IMMER (1 G	ANG)	
C311 C312 C313 C314 C315	1-102-953-00 1-102-953-00 1-102-816-00 1-102-978-00 1-102-944-00	CERAMIC CERAMIC CERAMIC CERAMIC CERAMIC	18PF 18PF 120PF 220PF 7PF	5% 5% 5% 0.5PF	50V 50V 50V 50V 50V	D301	<dio 8-719-911-19</dio 	DE> DIODE 188119			
C316 C317 C318 C319	1-102-944-00 1-102-816-00 1-102-074-00 1-106-375-12	CERAMIC CERAMIC CERAMIC MYLAR	7PF 120PF 0.001MF 0.022MF	0.5PF 5% 10% 10%	50V 50V 50V 250V	D303 D304 D305 D306	8-719-911-19 8-719-911-19 8-719-911-19	DIODE 1SS119 DIODE 1SS119 DIODE 1SS119			
C320 C321 C322 C323 C324	1-102-935-00 1-130-785-11 1-106-383-00 1-124-499-11 1-102-074-00	CERAMIC MYLAR MYLAR ELECT CERAMIC	2PF 0.47MF 0.047MF 1MF 0.001MF	0.25PF 10% 10% 20% 10%	100V 100V 100V 50V 50V	D307 D308 D310 D311 D312	8-719-911-19 8-719-911-19 8-719-911-19 8-719-911-19	DIODE 188119	 		
C325 C326 C327 C328 C329 C330	1-101-004-00 1-101-361-00 1-101-004-00 1-124-120-11 1-131-367-00 1-102-973-00	CERAMIC CERAMIC CERAMIC ELECT TANTALUM CERAMIC	0.01MF 150PF 0.01MF 220MF 22MF 100PF	5% 20% 10% 5%	50V 50V 50V 16V 50V	D313 D314 D315 D316 D317	8-719-911-19 8-719-911-19 8-719-911-19 8-719-911-19 8-719-911-19	DIODE ISS119 DIODE ISS119 DIODE ISS119 DIODE ISS119			
C331 C332 C333 C334 C335	1-124-927-11 1-130-783-00 1-124-499-11 1-106-375-12 1-106-375-12	ELECT MYLAR ELECT MYLAR MYLAR	4.7MF 0.33MF 1MF 0.022MF 0.022MF	20% 10% 20% 10% 10%	50V 100V 50V 250V 250V		<del 1-415-122-00 1-415-122-00</del 				
C336 C337 C339 C340 C341	1-124-927-11 1-130-834-00 1-106-375-12 1-130-783-00 1-130-783-00	MYLAR	4.7MF 1MF 0.022MF 0.33MF 0.33MF	20% 10% 10% 10% 10%	50V 63V 250V 100V 100V	IC301 IC302	<1C> 8-759-947-20 8-759-947-19				
C342 C343 C344 C345 C346	1-124-120-11 1-106-375-12 1-106-375-12 1-106-375-12 1-101-880-00	ELECT MYLAR MYLAR MYLAR CERAMIC	220MF 0.022MF 0.022MF 0.022MF 47PF	20% 10% 10% 10% 5%	16V 250V 250V 250V 250V	L301 L302	1-408-408-00	INDUCTOR INDUCTOR	150UH 8.2UH		
C347	1-106-375-12	MYLAR	0.022MF	10%	250V	L303 L304	1-404-539-11 1-404-554-11	COIL			



The components identified by shading and mark Aare critical for safety.

Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTIO	N -			REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
L305 L306 L307 L308	1-404-554-11 1-404-554-11 1-408-423-00 1-404-495-00	COIL	1500	Н			R350 R352 R353 R355	1-249-436-11 1-249-437-11 1-249-413-11 1-247-887-00	CARBON CARBON CARBON CARBON	39K 47K 470 220K	5% 5% 5%	1/4W 1/4W 1/4W 1/4W	
	<tra< td=""><td>NSISTOR></td><td></td><td></td><td></td><td></td><td>R356 R357 R399</td><td></td><td>CARBON</td><td>220K 1K</td><td>5% 5%</td><td>1/4W 1/4W</td><td></td></tra<>	NSISTOR>					R356 R357 R399		CARBON	220K 1K	5% 5%	1/4W 1/4W	
Q301 Q302	8-729-119-78 8-729-119-78	TRANSISTOR	2SC2785-	HFE			K399		CARBON	1M	5%	1/4W	
Q303 Q304 Q305	8-729-119-78 8-729-119-78 8-729-119-78	TRANSISTOR TRANSISTOR TRANSISTOR	2SC2785-	HFE				1-238-009-11		RBON 22			
Q307 Q308	8-729-900-80	TRANSISTOR TRANSISTOR	DTC114ES	HFE			RV302	1-238-016-11		RBON 10	K		
Q309	8-729-173-38	TRANSISTOR	2SA733-K				T301	<tra 1-404-584-11</tra 	NSFORMER> COLL				
R301	<res< td=""><td>ISTOR> CARBON</td><td>1.2K</td><td>E 97</td><td>1/4W</td><td></td><td></td><td></td><td>STAL></td><td></td><td></td><td></td><td></td></res<>	ISTOR> CARBON	1.2K	E 97	1/4W				STAL>				
R302 R303	1-249-401-11 1-249-412-11	CARBON CARBON	47 390	5%	1/4W 1/4W		X301	1-567-131-00		CRYSTAL			
R304 R305	1-249-408-11 1-249-416-11	CARBON CARBON	180 820	5%	1/4W 1/4W		 	<yc *<="" td=""><td>MODULE></td><td></td><td></td><td></td><td></td></yc>	MODULE>				
R306 R307 R308	1-249-419-11 1-249-431-11 1-249-417-11	CARBON CARBON CARBON	1.5K 15K 1K	5% 5% 5%	1/4W 1/4W 1/4W		YCM301	1: 235-753-21	YC MODULE				
R309 R310	1-249-409-11 1-247-891-00	CARBON CARBON	220 330K	5% 5%	1/4W 1/4W			************ *1-628-600-11		******	*****	*****	*******!!
R311 R312 R313	1-247-891-00 1-249-405-11 1-249-405-11	CARBON CARBON CARBON	330K 100 100		1/4W 1/4W		 	-1 020 000 11	*****				
R314 R315	1-249-403-11 1-249-405-11 1-249-437-11	CARBON CARBON	100 100 47K	5% 5% 5% 5%	1/4W 1/4W 1/4W		CALCA		NECTOR>	OD 45			
R316 R317	1-249-404-00 1-249-429-11	CARBON CARBON	82 10K	5% 5%	1/4W 1/4W		CNF62	*1-566-664-11 *1-566-664-11	PIN, CONNECT PIN, CONNECT	OR 4P			
R318 R319 R320	1-247-848-11 1-249-419-11 1-249-437-11	CARBON CARBON CARBON	5.1K 1.5K 47K	5% 5% 5%	1/4W 1/4W 1/4W		 	<fus< td=""><td>E></td><td></td><td></td><td></td><td></td></fus<>	E>				
R321 R322	1-249-418-11 1-249-417-11	CARBON CARBON	1.2K 1K	5% 5%	1/4W 1/4W		F601 ∆	. 1-576-016-11 1-533-087-00	FUSE, GLASS- HOLDER, FUSE	TUBE (T ; F601	IME-LA	6) 3.1	5A/250V
R323 R324 R325	1-249-410-11 1-249-421-11 1-249-419-11	CARBON CARBON	270 2.2K 1.5K	5% 5% 5%	1/4W 1/4W 1/4W		É ! !	<swi< td=""><td>TCH></td><td></td><td></td><td></td><td></td></swi<>	TCH>				
R326	1-249-417-11	CARBON	1 K		1/4W		1	. 1-571-433-11					
R327 R328 R329	1-249-415-11 1-249-437-11 1-247-891-00	CARBON CARBON CARBON	680 47K 330K	5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/4W 1/4W 1/4W			************* *A-1330-946-A	C BOARD, COM	PLETE	*****	*****	******1''
R330 R331	1-249-440-11 1-247-895-00	CARBON CARBON	82K 470K	5% 5% 5%	1/4W 1/4W		: :	*4-374-704-01	cover (rear		v vol		
R332 R333 R334	1-247-903-00 1-214-907-00 1-249-426-11	CARBON METAL CARBON	1M 56K 5.6K	5% 1% 5%	1/4W W 1/4W		i 1 1	*4-374-717-01	COVER (MAIN)	, CV VOI	L		
R335 R336	1-249-439-11 1-249-425-11	CARBON CARBON	68K 4.7K	5%	1/4W 1/4W		C701	<cap 1-102-980-00</cap 	ACITOR>	27005		c •⁄	EO!
R337 R338	1-249-413-11 1-249-413-11	CARBON CARBON	470 470	5% 5% 5%	1/4W 1/4W		C701 C702 C703	1-102-980-00 1-102-820-00	CERAMIC CERAMIC CERAMIC	270PF 270PF 330PF		5% 5% 5%	50V 50V 50V
R341 R343	1-249-431-11 1-247-885-00	CARBON CARBON	15K 180K	5%	1/4W 1/4W		C704 C705	1-102-114-00 1-102-114-00	CERAMIC CERAMIC	470PF 470PF		10% 10%	50V 50V
R344 R345 R346	1-249-432-11 1-249-433-11 1-249-413-11	CARBON CARBON CARBON	18K 22K 470	5% 5% 5% 5%	1/4W 1/4W 1/4W		C706 C707 C708	1-102-114-00 1-123-947-00 1-162-116-00	CERAMIC ELECT CERAMIC	470PF 10MF 680PF		10% 20% 10%	50V 250V 2KV
R347 R348	1-249-417-11 1-249-435-11	CARBON CARBON	1 K 33 K	5% 5%	1/4W 1/4W		C709 C710	1-136-666-11 1-124-477-11	FILM ELECT	0.01MF 47MF		5% 20%	1KV 16V
R349	1-249-436-11	CARBON	39K	5%	1/4W		C711	1-102-074-00	CERAMIC	0.001MI	7	10%	50V

REF.NO. PART NO. DESCRIPTION REMARK (REF.NO. PART NO. DESCRIPTION	REMARK
C712 1-102-074-00 CERAMIC 0.001MF 10% 50V C713 1-102-074-00 CERAMIC 0.001MF 10% 50V R722 1-216-463-00 METAL OXIDE 12K 5% 2W C714 1-162-318-11 CERAMIC 0.001MF 10% 500V R726 1-202-719-00 SOLID 1M 10% 1/2W R727 1-202-838-00 SOLID 100K 10% 1/2W R728 1-202-842-11 SOLID 220K 10% 1/2W R729 1-216-348-00 WIREWOUND 0.82 10% 1/2W	
CNC71 *1-508-786-00 PIN, CUNNECTOR (5MM PITCH) 2P R731 1-202-719-00 SOLID 1M 10% 1/2W CNC72 *1-560-123-00 PLUG, CONNECTOR (2.5MM) 3P R732 1-247-895-00 CARBON 470K 5% 1/4W CNC73 *1-560-126-00 PLUG, CONNECTOR (2.5MM) 6P R734 1-249-421-11 CARBON 2.2K 5% 1/4W CNC74 *1-508-765-00 PIN, CONNECTOR (5MM PITCH) 3P R735 1-249-421-11 CARBON 2.2K 5% 1/4W R736 1-249-421-11 CARBON 2.2K 5% 1/4W	
VARIABLE RESISTOR> D701 8-719-911-19 D10DE ISS119	
D707 8-719-911-19 D10DE 1SS119 D708 8-719-911-19 D10DE 1SS119 D709 8-719-911-19 D10DE 1SS119 **A-1345-840-A D BOARD, COMPLETE ***********************************	******
J901 1-526-814-11 SOCKET, PICTURE TUBE *4-341-752-01 EYELET <coil></coil>	
C001	50V 50V 50V 50V 100V
Q701 8-729-119-78 TRANSISTOR 2SC2785-HFE C007 1-124-927-11 ELECT 4.7MF 20% Q702 8-729-119-78 TRANSISTOR 2SC2785-HFE C009 1-102-111-00 CERAMIC 270PF 10% Q703 8-729-119-78 TRANSISTOR 2SC2785-HFE C010 1-102-965-00 CERAMIC 39PF 5% Q704 8-729-906-70 TRANSISTOR BF871 C011 1-102-965-00 CERAMIC 39PF 5% Q705 8-729-906-70 TRANSISTOR BF871 C012 1-101-004-00 CERAMIC 0.01MF	50V 50V 50V 50V 50V
Q706 8-729-906-70 TRANSISTOR BF871 C013 1-102-959-00 CERAMIC 22PF 5% Q707 8-729-200-17 TRANSISTOR 2SA1091-0 C014 1-101-004-00 CERAMIC 0.01MF Q708 8-729-200-17 TRANSISTOR 2SA1091-0 C015 1-124-479-11 ELECT 330MF 20% Q709 8-729-200-17 TRANSISTOR 2SA1091-0 C016 1-102-978-00 CERAMIC 220PF 5% C019 1-126-233-11 ELECT 22MF 20%	50V 50V 25V 50V 50V
CO20	50V 50V 50V 50V 16V
R706 1-249-401-11 CARBON 47 5% 1/4W C043 1-102-116-00 CERAMIC 680PF 10% C043 1-102-978 00 CERAMIC 220PF 5% R707 1-249-401-11 CARBON 47 5% 1/4W C071 1-106-220-00 MYLAR 0.1MF 10% R708 1-249-417-11 CARBON 1K 5% 1/4W C072 1-106-383-00 MYLAR 0.047MF 10% R709 1-249-416-11 CARBON 820 5% 1/4W	50V 50V 50V 100V 100V
R710 1-249-413-11 CARBON 470 5% 1/4W C073 1-101-004-00 CERAMIC 0.01MF C075 1-102-074-00 CERAMIC 0.01MF C075 1-102-074-00 CERAMIC 0.001MF C075 1-102-074-00 CERAMIC 0.001MF C076 1-102-125-00 CERAMIC 0.0047MF C078 1-247-881-00 CARBON 120K 5% 1/4W C151 1-124-477-11 ELECT 47MF C078 1-102-074-00 CERAMIC 0.0047MF C079 1-102-074-00 CERAMIC 0.001MF C079 1-102-074-00 CERAMIC 0.01MF C079 1-102-074-00 CERAMIC 0.001MF C079 1-102-074-00 CER	50V 50V 50V 16V 25V
R716 1-249-417-11 CARBON 1K 5% 1/4W C154 1-106-216-00 MYLAR 0.068MF 10% C155 1-106-216-00 MYLAR 0.068M	100V 100V 50V 50V 16V



The components identified by shading and mark Aare critical for safety.
Replace only with part number specified.

REF.NO. PART NO.	DESCRIPTION	1		REMARK	REF.NO. PART NO.		N 		REMARK
C201 1-124-47 C202 1-106-22 C203 1-124-79 C204 1-106-38 C205 1-123-87	9-11 ELECT 0-00 MYLAR 1-11 ELECT 3-00 MYLAR 5-11 ELECT	330MF 0.1MF 1MF 0.047MF 10MF	20% 10% 20% 10% 20%	25V 100V 50V 100V 50V	C614 1-126 101-11 C615 A . 1-162-578-51 C616 A . 1-162-578-51 C618 1-126-233-11 C620 A . 1-136-519-11 C621 A . 1-136-519-11	CERAMIC	0.0047MF 22MF	20% 20% 20% 20%	16V 400V 400V 50V 300V
C206 1-106-37 C207 1-106-22 C208 1-126-10 C209 1-102-07 C210 1-102-11	9-12 MYLAR 0-00 MYLAR 4-11 ELECT 4-00 CERAMIC 4-00 CERAMIC	0.033MF 0.1MF 470MF 0.001MF 470PF	10% 10% 20% 10% 10%	250V 100V 25V 50V 50V	C621 A. 1-136-519-11 C621 A. 1-136-519-11 C622 A. 1-162-578-51 C623 A. 1-162-578-51 C626 A. 1-102-316-91 C629 A. 1-102-316-91	CERAMIC CERAMIC CERAMIC	0.47MF 0.47MF 0.0047MF 0.0047MF 15PF 15PF	20% 20% 20% 20% 5% 5%	300V 300V 400V 400V 500V
C212	3-00 CERAMIC 5-00 CERAMIC 3-00 CERAMIC 4-00 CERAMIC 2-00 ELECT	100PF 0.022MF 0.0047MF 470PF 0.47MF	5% 10% 20%	50V 50V 50V 50V 50V	C631 1-102-244-00 C801 1-124-499-11 C802 1-123-932-00 C803 1-106-383-00 C804 1-106-357-00			10% 20% 20% 20% 10%	500V 50V 160V 100V 400V
C407 1-124-90 C409 1-124-47 C410 1-124-47 C411 1-102-07		47MF 0.47MF 47MF 47MF 0.001MF	20% 20% 10%	16V 50V 16V 16V 50V	C805 1-102-214-00 C806 A. 1-162-116-51 C807 1-130-783-00 C808 1-136-188-11 C811 1-123-875-11	CERAMIC	220PF 680PF 0.33MF 0.068MF 10MF	10% 10% 10% 10%	500V 2KV 100V 160V 50V
C412 1-126-10 C413 1-126-23 C417 1-101-00 C418 1-102-07 C433 1-102-12	5-UU LEKAMIL	100MF 22MF 0.022MF 0.001MF 0.0047MF	20% 20% 10%	16V 50V 50V 50V 50V	C812	FILM CERAMIC MYLAR ELECT	0.0073MF 0.001MF 0.022MF 1MF 100MF	3% 10% 10% 20% 20%	2KV 50V 250V 250V 16V
C504 1-124-48 C505 1-124-12	2-11 ELECT		10% 5% 20% 20%	50V 50V 50V 25V 50V	i i	CERAMIC MYLAR FILM MYLAR		10% 10% 5% 10% 20%	50V 100V 160V 400V 250V
C506 1-130-83 C507 1-124-91 C508 1-106-22 C510 1-126-23 C551 1-124-92		0.82MF 470MF 0.1MF 22MF 4.7MF	10% 20% 10% 20% 20%	63V 50V 100V 50V 50V	C852 1-162-114-00 C853 1-162-318-11 C854 1-110-180-81 C855 1-110-180-81 C856 1-162-318-11	CERAMIC	0.0047MF 0.001MF 0.27MF 0.27MF 0.001MF	10% 10% 10%	2KV 500V 100V 100V 500V
U556 1-101-36	7-11 ELECT 0-00 MYLAR 3-11 ELECT 5-11 ELECT 1-00 CERAMIC	4.7MF 0.1MF 22MF 2.2MF 150PF	20% 10% 20% 20% 5%	50V 100V 50V 50V 50V	C857 1-106-375-12 C858 1-123-357-00 C859 1-126-101-11 C860 1-102-228-00	MYLAR ELECT ELECT		10% 20% 20% 10%	250V 50V 16V 500V
C558 1-130-78		0.33MF 0.33MF 0.0039MF 100MF 0.1MF	10% 10% 10% 20% 10%	100V 100V 400V 16V 100V	<f1 CF001 1-577-082-11</f1 	LTER> VIBRATOR, C	ERAMIC		
C562 1-161-96 C563 1-124-47 C564 1-136-29 C565 1-106-22 C566 1-102-94	7-11 ELECT 8-00 FILM 8-00 MYLAR	0.0022MF 47MF 0.0033MF 0.22MF 5PF	10% 20% 2% 10% 1PF	3KV 16V 100V 100V 50V	<pre><cod *1-508-765-900<="" *1-560-290-900="" *1-565-394-11="" cnc61="" cnd21="" cnd42="" cnd43="" pre=""></cod></pre>	PIN, BOARD PIN, BOARD		NECTOR - NECTOR -	
C567 1-106-37 C568 1-161-96 C570 1-124-90 C571 1-126-10 C601 1 1-161-96	1-00 CERAMIC 12-00 ELECT 1-11 ELECT	0.015MF 0.0022MF 0.47MF 100MF 0.0047MF	10% 10% 20% 20%	400V 3KV 50V 16V 250V	CND62 *1-565-458-11 CND81 *1-564-038-00 CND82 *1-508-768-00 CND83 *1-508-784-00	PIN, CONNEC CONNECTOR P PIN, CONNEC	TOR 3P LUG, DY (MIN' TOR (5MM PIT)	F) 6P CH) 6P	
C602 A. 1-161-96 C603 A. 1-161-96 C604 I-125-29 C605 I-161-75 C606 I-136-63	04-61 CERAMIC 03-00 ELECT(BLOCK) 04-00 CERAMIC	0.0047MF 0.0047MF 220MF 0.001MF 0.047MF	10% 10%	250V 250V 400V 2KV 630V	1		9		
C607 1-106-38 C608 1-162-11 C609 1-124-34 C610 1-124-55	6-00 CERAMIC 7-00 ELECT	0.047MF 680PF 100MF 1000MF	10% 10% 20% 20%	100V 2KV 160V 25V	D004	DIODE PLED-	H544CL-6		

The components identified by shading and mark Aare critical for safety.
Replace only with part number specified.



number specified.					
REF.NO. PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION
D008 8-719-911-19 D009 8-719-911-19 D010 8-719-911-19	D10DE 1SS119 D10DE 1SS119 D10DE 1SS119 D10DE 1SS119		10801	4-365-216-00 *4-368-683-01 8-759-145-58	SPACER, MICA: IC601 SPRING: IC601 IC UPC4558C
D011 8-719-911-19 D016 8-719-911-19	DIODE 188119 DIODE 188119			8 · 759 · 601 · 39 • 4 · 368 · 683 · 01	IC UPC78M12H SPRING: IC851
0017 8-719-911-19 0019 8-719-911-19 0025 8-719-109-71 0151 8-719-911-19	D10DE 188119 D10DE 188119 D10DE RD3.9ES-B1 D10DE 188119			<jac 1~507~678~00</jac 	K> JACK
D156 8-719-911-19 D201 8-719-911-19 D402 8-719-109-96 D403 8-719-109-96	DIODE 188119 DIODE 188119 DIODE RD6.8ES-BI DIODE RD6.8ES-BI		J401 J402		SOCKET 21P JACK BLOCK, PIN (L TYPE) 2P
D404 8-719-109-96	DIODE RD6.8ES-B1		1.002	1~408~411~00	INDUCTOR 15UH
D405 8-719-911-19 D406 8-719-911-19 D407 8-719-911-19 D408 8-719-911-19 D410 8-719-911-19	DIODE 188119 DIODE 188119 DIODE 188119 DIODE 188119 DIODE 188119		L003 L004 L005 L151	1-408-409-00 1-408-415-00 1-410-663-31 1-408-226-00	INDUCTOR 10UH INDUCTOR 33UH INDUCTOR 10UH INDUCTOR 82UH
D411 8-719-911-19 D413 8-719-110-30 D414 8-719-911-19 D416 8-719-911-19 D416 8-719-911-19	DIODE 1SS119 DIODE RD12ES-B1 DIODE 1SS119 DIODE 1SS119 DIODE 1SS119		L152 L153 L201 L202 L401	1-410-683-31 1-408-399-00 1-408-409-00 1-408-409-00 1-408-417-00	INDUCTOR
D419 8-719-911-19 D420 8-719-911-19 D421 8-719-911-19 D501 8-719-911-55 D551 8-719-911-55	DIODE 1SS119 DIODE 1SS119 DIODE 1SS119 DIODE U056 DIODE U056		L403 L410 L501 L803 L804	1-408-409-00 1-410-316-11 1-408-226-00 1-407-365-00 1-459-105-21	INDUCTOR 100H INDUCTOR 1UH INDUCTOR 82UH COIL, CHOKE COIL(WITH CORE)
D601 8-719-946-90 D602 8-719-300-65 D603 8-719-911-55 D604 8-719-901-58 D605 8-719-300-33	DIODE KBU4JL-6088 DIODE ESIF DIODE UO5G DIODE RGP15J DIODE RU3AM		L805 L806 L821 L822 L823	1-459-635-11 1-459-856-11 1-459-881-11 1-410-067-21 1-459-855-11	HLC COIL, FERRITE COIL, CHOKE 2.7MMH INDUCTOR 4.7MMH COIL, FERRITE
D606 8-719-908-06 D607 8-719-300-33	DIODE ERA81-005 DIODE RU3AM		: : : !	<1.0	L.INK>
D608 8-719-300-33 D609 8-719-911-55 D610 8-719-911-55	DIODE RUSAM DIODE RUSAM DIODE RUSG DIODE RUSG		PS501 <u>&</u> PS802 <u>&</u>	. 1-532-679-91 . 1-532-679-91	LINK, IC 0.6A LINK, IC 0.6A
D611 8-719-303-49 D801 8-719-945-80	DIODE ERCO6-15S				NSISTOR>
D802 8-719-901-58 D851 8-719-300-33 D852 8-719-300-65 D853 8-719-300-33	DIODE RUSAM DIODE ESIF DIODE RUSAM		1 Q001 Q003 Q004 Q005	8-729-900-36 8-729-900-63 8-729-119-78 8-729-119-78	TRANSISTOR DTC124ES TRANSISTOR DTA124ES TRANSISTOR 2SC2785-HFE TRANSISTOR 2SC2785-HFE TRANSISTOR DTC124ES
D855 8-719-300-33 D857 8-719-911-55 D858 8-719-911-55	DIODE RUSAM DIODE RUSAM DIODE RUSG DIODE RUSG		Q008 Q009 Q012 Q015	8-729-900-36 8-729-900-74 8-729-173-38 8-729-119-78	TRANSISTOR DTC124ES TRANSISTOR DTC143TS TRANSISTOR 2SA733-K TRANSISTOR 2SC2785-HFE
<10>	>		Q071 Q151	8-729-173-38 8-729-900-61	TRANSISTOR 2SA733-K TRANSISTOR DTA114ES
1C001 8-759-630-92 1C002 8-752-330-60 1C003 8-741-139-80 1C004 8-759-157-40 1C005 8-759-708-05	IC M50436-616SP IC CXK1012P IC BX-1398 IC UPC574J IC NJM78L05A		Q152 Q154 Q155 Q158 Q158 Q402	8-729-900-61 8-729-900-61 8-729-119-78 8-729-901-59 8-729-119-78	TRANSISTOR DTAILLES TRANSISTOR DTAILLES TRANSISTOR 2SC2785-HFE TRANSISTOR BF199 TRANSISTOR 2SC2785-HFE
1C201 8-759-980-45 1C401 8-759-340-53 1C402 8-759-946-32 1C501 8-759-113-05 *4-368-683-01	IC TDA1013A-N4 IC HD14053BP IC TEA2014A IC UPC1488H SPRING; IC501		Q403 Q404 Q405 Q406 Q501	8-729-173-38 8-729-173-38 8-729-173-38 8-729-900-80 8-729-119-78	TRANSISTOR 2SA733-K TRANSISTOR 2SA733-K TRANSISTOR 2SA733-K TRANSISTOR DTC114ES TRANSISTOR 2SC2785-HFE
IC551 8-759-973-52 IC601 8-749-901-65	IC TDA2579A/N7 IC STR54041		Q551 Q601	8~729~173~38 8~729~906~74	TRANSISTOR 2SA733-K TRANSISTOR BC637-16



REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
Q801 Q802 Q803 Q804	8-729-906-69 *4-389-343-01 8-729-920-92	TRANSISTOR 2S TRANSISTOR BU SPRING; Q802 TRANSISTOR 2S TRANSISTOR 2S	506DF D2096-1	EF		R084 R085 R086 R151	1-249-424-11 1-247-881-00 1-249-429-11 1-249-405-11	CARBON CARBON CARBON	3.9K 120K 10K 100	5% 5%	1 1 4W 1 / 4W 1 / 4W 1 / 4W	
	<res< td=""><td>ISTOR></td><td></td><td></td><td></td><td>R152 R153 R154</td><td>1-249-429-11 1-249-433-11 1-249-429-11</td><td>CARBON CARBON CARBON</td><td>10K 22K 10K</td><td>5% 5% 5%</td><td>174W 174W 174W</td><td></td></res<>	ISTOR>				R152 R153 R154	1-249-429-11 1-249-433-11 1-249-429-11	CARBON CARBON CARBON	10K 22K 10K	5% 5% 5%	174W 174W 174W	
R001 R002	1-249-438-11 1-249-440-11	CARBON CARBON	56K 82K	5% 1/4W 5% 1/4W		R155 R156	1-249-418-11 1-247-891-00	CARBON CARBON	1.2K 330K	5% 5%	1/4W 1/4W	
R004 R005 R006	1-249-439-11 1-249-413-11 1-249-441-11	CARBON CARBON CARBON	68K 470 100K	5% 1/4W 5% 1/4W 5% 1/4W		R157 R158 R160	1-249-421-11 1-249-421-11 1-249-405-11	CARBON CARBON CARBON	2.2K 2.2K 100	5% 5% 5%	1/4W 1/4W 1/4W	
R008 R009	1-249-429-11 1-249-429-11	CARBON CARBON	10K 10K	5% 1/4W 5% 1/4W 5% 1/4W 5% 1/4W		R162 R163	1-249-425-11 1-249-425-11	CARBON CARBON	4.7K 4.7K	5% 5%	1/4W 1/4W	
R010 R011 R012	1-249-433-11 1-249-433-11 1-249-433-11	CARBON CARBON CARBON	22K 22K 22K	5% 1/4W 5% 1/4W 5% 1/4W		R164 R172 R173	1-249-413-11 1-249-422-11 1-249-429-11	CARBON CARBON CARBON	470 2.7K 10K	5% 5% 5%	174W 174W 174W	
R013 R014	1-249-433-11 1-215-900-11	CARBON METAL OXIDE	22K 22K	5% 1/4W 5% 2W		R180 R185	1·249·419·11 1-249·439·11	CARBON CARBON	1.5K 68K	5% 5%	174W 174W	
R015 R016 R017	1-249-421-11 1-249-433-11 1-249-407-11	CARBON CARBON CARBON	2.2K 22K 150	5% 2W 5% 1/4W 5% 1/4W 5% 1/4W		R186 R201 R202	1-249-441-11 1-249-387-11 1-247-887-00	CARBON CARBON CARBON	100K 3.3 220K	5% 5% 5%	174W 174W 174W	
R018 R019	1-249-417-11 1-249-413-11	CARBON CARBON	1K 470	5% 1/4W 5% 1/4W 5% 1/4W 5% 1/4W		R203 R204	1: 249: 411-11 1: 247-739-11	CARBON CARBON	330 100	5% 5%	1/4W 1/2W	
R020 R021 R022	1-249-413-11 1-249-413-11 1-249-411-11	CARBON CARBON CARBON	470 470 330	5% 1/4W 5% 1/4W 5% 1/4W		R401 R402 R403	1-247-804-11 1-247-804-11 1-247-804-11	CARBON CARBON CARBON	75 75 75	5% 5% 5%	174W 174W 174W	
R023 R025	1-249-416-11 1-249-417-11	CARBON CARBON	820 1K	5% 1/4W 5% 1/4W 5% 1/4W 5% 1/4W		R404 R405	1-247-804-11 1-249-411-11	CARBON CARBON	75 330	5%	1/4W 1/4W	
R029 R030 R035	1-249-429-11 1-249-429-11 1-249-431-11	CARBON CARBON CARBON	10K 10K 15K	5% 1/4W 5% 1/4W 5% 1/4W		R406 R407 R408	1-249-411-11 1-249-411-11 1-249-431-11	CARBON CARBON CARBON	330 330 15K	5% 5% 5%	1/4W 1/4W 1/4W	
R037 R038	1-249-429-11 1-249-429-11	CARBON CARBON	10K 10K	5% 1/4W 5% 1/4W		R409 R413	1-249-431-11 1-249-425-11	CARBON CARBON	15K 4.7K	5% 5%	1/4W 1/4W	
R039 R040 R042	1-249-417-11 1-249-430-11 1-249-433-11	CARBON CARBON CARBON	1 K 1 2 K 2 2 K	5% 1/4% 5% 1/4% 5% 1/4%		R410 R411 R412	1-249-409-11 1-249-409-11 1-249-409-11	CARBON CARBON CARBON CARBON	220 220 220 22K	5% 5% 5% 5%	1/4W 1/4W 1/4W 1/4W	
R043 R044	1-249-429-11 1-249-433-11 1-249-425-11	CARBON CARBON	10K 22K	5% 1/4W 5% 1/4W 5% 1/4W		R414 R416	1-249-433-11 1-247-804-11	CARBON	75	5%	1/4W	
R046 R051 R052	1-249-427-11	CARBON CARBON CARBON	4.7K 6.8K 470	5% 1/4W 5% 1/4W 5% 1/4W		R418 R419 R420	1-249-417-11 1-249-425-11 1-249-413-11	CARBON CARBON	1K 4.7K 470	5%	1/4W 1/4W 1/4W	
R055 R056	1-249-413-11 1-249-423-11	CARBON CARBON	470 3.3K	5% 1/4W 5% 1/4W		R422	1-249-404-00 1-249-404-00	CARBON	220 82	5%	1/4W 1/4W	
R058 R059 R060	1-249-429-11 1-249-426-11 1-249-417-11	CARBON CARBON CARBON	10K 5.6K 1K	5% 1/4W 5% 1/4W 5% 1/4W		R423 R424 R425	1-249-438-11 1-249-437-11 1-249-437-11	CARBON CARBON CARBON	56K 47K 47K	5% 5%	174W 174W 174W	
R061 R063 R064	1-249-413-11 1-249-422-11	CARBON CARBON	470 2.7K	5% 1/4W 5% 1/4W		R426 R427	1-249-405-11 1-247-804-11	CARBON CARBON CARBON	100 75	5% 5%	174W 174W	
R065 R066	1-249-417-11 1-249-433-11 1-249-425-11	CARBON CARBON CARBON	1 K 22 K 4 . 7 K	5% 1/4W 5% 1/4W 5% 1/4W		R428 R429 R430	1-249-432-11 1-249-409-11 1-249-437-11	CARBON CARBON	18K 220 47K	5% 5% 5%	174W 174W 174W 174W	
R070 R071 R072	1-249-429-11 1-249-413-11	CARBON CARBON CARBON	10K 470 100K	5% 1/4W 5% 1/4W 5% 1/4W		R431 R432	1-249-441-11 1-249-437-11 1-249-415-11	CARBON CARBON CARBON	100K 47K	5%	1/4W 1/4W	
R073 R074	1-249-441-11 1-249-435-11 1-249-429-11	CARBON CARBON	33K 10K	5% 1/4W 5% 1/4W 5% 1/4W		R434 R435 R436	1-249-440-11 1-249-409-11	CARBON CARBON	680 82K 220	5% 5% 5%	1/4W 1/4W 1/4W 1/4W	
R075 R076 R077	1-249-431-11 1-249-423-11 1-249-435-11	CARBON CARBON CARBON	15K 3.3K 33K	5% 1/4W 5% 1/4W		R437 R444	1-249-429-11 1-249-411-11	CARBON CARBON	10K 330	5% 5%	1/4W 1/4W 2W	E
R078 R079	1-249-435-11 1-249-427-11 1-249-429-11	CARBON CARBON CARBON	6.8K 10K	5% 1/4W 5% 1/4W 5% 1/4W		R445 R501 R502	1-216-452-11 1-249-425-11 1-247-744-11	METAL OXIDE CARBON CARBON METAL OXIDE	180 4.7K 270	5% 5% 5%	1/4₩ 1/2₩	F
R080	1-249-429-11	CARBON	10K	5% 1/4W		R503 R504	1-215-867-00 1-247-895-00	METAL OXIDE CARBON	470 470K	5% 5%	1W 1/4W	

The components identified by shading and mark ♠are critical for safety.
Replace only with part number specified.



BEF.NO. PART NO.	DESCRIPTION		REMARK	REF.NO. PART NO. DESCRIPTION	REMARK
R505 1-249-429-11 R506 1-249-423-11 R507 1-249-435-11 R508 1-216-347-11 R509 1-247-893-11	CARBON CARBON CARBON METAL OXIDE CARBON	10K 5% 3.3K 5% 33K 5% 0.68 5% 390K 5%	1/4W 1/4W 1/4W 1W F 1/4W	R855 1-202-830-00 SOLID 10K 10% 1/2W R856 1-217-825-11 FUSIBLE 8.2K 5% 1/4W R857 1-247-887-00 CARBON 220K 5% 1/4W R858 1-215 882-00 METAL OXIDE 22 5% 2W	
R510 1-249-439-11 R511 1-247-891-00 R513 1-249-424-11 R551 1-212-883-00 R552 1-249-419-11	CARBON CARBON CARBON FUSIBLE CARBON	68K 5% 330K 5% 3.9K 5% 120 5% 1.5K 5%	1/4W 1/4W 1/4W 1/4W 1/4W	<pre>RV401 1-238*163-11 RES, VAR, CARBON 10K RV501 1-238*016*11 RES, ADJ, CARBON 10K RV552 1-238*020*11 RES, ADJ, CARBON 100K</pre>	
R553 1-249-426-11 R554 1-249-404-00 R555 1-249-423-11 R556 1-249-418-11 R558 1-249-417-11	CARBON CARBON CARBON CARBON CARBON	5.6K 5% 82 5% 3.3K 5% 1.2K 5% 1K 5%	174W 174W 174W 174W 174W	RV553 1-238-016-11 RES, ADJ, CARBON 10K RV801 1-223-102-00 RES, ADJ, WIREWOUND 120 RV802 1-238-019-11 RES, ADJ, CARBON 47K	
R559 1-249-434-11 R560 1-247-887-00 R561 1-249-412-11 R562 1-249-432-11 R563 1-249-417-11	METAL METAL CARBON METAL CARBON	27K 5% 220K 5% 390 5% 18K 5% 1K 5%	1/4W 1/4W 1/4W 1/4W 1/4W		
R564 1-249-410-11 R565 1-215-454-00 R567 1-247-887-00 R569 1-249-431-11 R571 1-249-436-11	CARBON METAL CARBON CARBON CARBON	270 5% 24K 1% 220K 5% 15K 5% 39K 5%	1/4W 1/6W 1/4W 1/4W 1/4W	S005 1-571-532-21 SWITCH, TACTIL S006 1-571-532-21 SWITCH, TACTIL S007 1-571-532-21 SWITCH, TACTIL S008 1-571-532-21 SWITCH, TACTIL S009 1-571-532-21 SWITCH, TACTIL S009 1-571-532-21 SWITCH, TACTIL	
R572 1-249-405-11 R573 1-249-433-11 R574 1-249-439-11 R575 1-249-421-11 R576 1-249-432-11	CARBUN CARBON CARBON CARBON CARBON	100 5% 22K 5% 68K 5% 2.2K 5% 18K 5%	1/4W 1/4W 1/4W 1/4W 1/4W	<spark gap=""> SG801 1-519-422-11 GAP, SPARK</spark>	
k601 ▲ 1-205-909-11 R602 1-214-931-00 R603 1-215-903-11 R604 1-247-750-11 R605 ▲ 1-247-289-11	WIREWOUND CARBON METAL OXIDE CARBON CARBON	3.3 5% 560K 5% 68K 5% 680 5% 8.2M 5%	10W 1/2W 2W 1/2W 1W	<transfurmer p="" →<=""> T601 ★ 1-449-275-12 S.R.T T603 ★ 1-421-776-11 LFT T604 ★ 1-424-078-11 TRANSFORMER, TRIGGER PULSE</transfurmer>	
R606 1-212-877-11 R608 1-216-449-11 R609 1-207-905-00 R610 1-247-887-00 R612 1-217-809-91	FUSIBLE METAL OXIDE WIREWOUND CARBON FUSIBLE	68 5% 56 5% 0.27 10% 220K 5% 0.33 5%	1/4W 2W 2W 1/4W 1/4W	T605 A. 1-421-862-11 LFT T801 1-437-078-00 TRANSFORMER, HORIZONTAL DRIVE	
R613 1-217-811-91 R615 1-249-399-11 R617 1-216-354-11 R801 1-217-811-91 R802 1-205-642-00	FUSIBLE CARBON METAL OXIDE FUSIBLE WIREWOUND	0.47 5% 33 5% 2.7 5% 0.47 5% 3.3K 10%	1/4W 1/4W 1W F 1/4W F	<pre><thermistor>> THGOL♠ 1-806-165: 11 THERMISTOR (POSITIVE) <tuner></tuner></thermistor></pre>	5 -
R804 1-217-822-91 R805 1-249-399-11 R806 1-249-421-11 R807 1-212-877-11 R808 1-216-347-11	FUSIBLE CARBON CARBON FUSIBLE METAL OXIDE	4.7K 5% 33 5% 2.2K 5% 68 5% 0.68 5%	1/4W 1/4W 1/4W 1/4W 1W F	TU1012 1-463-881-11 TUNER, ET (UV-617)	
R809 1-249-421-11 B810 1-202-721-00 R822 1-247-903-00 R823 1-217-820-91 R824 1-249-434-11	CARBON SOLID CARBON FUSIBLE CARBON	2.2K 5% 1.5M 10% 1M 5% 3.3K 5% 27K 5%	1/4W 1/2W 1/4W 1/4W 1/4W	VIF101 1-464-960-11 IF BLOCK (IFG-389) ***********************************	******
RS26 1-249-430-11 RS27 1-249-417-11 RS28 1-249-438-11 RS29 1-247-883-00 RS30 1-249-429-11	CARBON EARBON CARBON CARBON CARBON	12K 5% 1K 5% 56K 5% 150K 5% 10K 5%	1/4W 1/4W 1/4W 1/4W 1/4W	Δ.1-451-304-21 DEFLECTION YOKE (Y16SXA) 1-452-032-00 MAGNET, DISK; 10MM φ 1-452-094-00 MAGNET, ROTATABE DISK; 15MM φ 1-452-277-00 MAGNET, BMC	
R831 1-249-423-11 R833 1-212-857-00 R852 1-216-431-11 R854 1-217-811-91	CARBON FUSIBLE METAL OXIDE FUSIBLE	3.3K 5% 10 5% 560 5% 0.47 5%	1/4W 1/4W 1W 1/4W	1-503-344-21 SPEAKER (8CM CONE TYPE) Δ.1-559-824-11 CORD, POWER (WITH CONNECTOR) L901 Δ.1-426-317-21 COLL, DEGAUSSING	

KV-M16D RM-658

The components identified by shading and mark Aare critical for safety.
Replace only with part number specified.

REF.NO. PART NO.

DESCRIPTION

REMARK

V901 ∆.8-738-852-05 PICTURE TUBE (A37JUW10X)

ACCESSORIES AND PACKING MATERIALS

PART NO.	DESCRIPTION	REMARK
A-1470-839-A 1-417-154-11 1-501-284-00 3-786-938-11 *4-384-927-01	COMMANDER ASSY (RM-658) MATCHING TRANSFORMER, ANTENNA ANTENNA, TELESCOPIC MANUAL, INSTRUCTION BAG, PROTECTION	
*4-391-427-01 *4-391-428-01 *4-391-429-01	CUSHION (UPPER) (ASSY) CUSHION (LOWER) (ASSY) INDIVIDUAL CARTON	